







|     |                                          |             |
|-----|------------------------------------------|-------------|
| 7   | Intake air temperature sensor cover      | —           |
| 6   | Handle                                   | —           |
| 5   | Liquid Pipe Connection                   | —           |
| 4   | Gas Pipe Connection                      | —           |
| 3   | Power and communication cable connection | —           |
| 2   | Control cover & SVC valve cover          | —           |
| 1   | Air Outlet                               | —           |
| No. | Part Name                                | Description |